



TESTING KITS FOR DRUGS

Procedure Card for IDT9009T

DRUGS GENERAL SCREENING

Surface Test

Read Before Use

As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

Test Preparation	1	Remove the Smart-Tip™ probe from test unit.	Sample suspected powder, surface or liquid. (Not for use with plant materials.)				
			2	<table border="1"> <thead> <tr> <th style="text-align: center;">Powders & Traces</th> <th style="text-align: center;">Liquids</th> </tr> </thead> <tbody> <tr> <td>Swipe the paper of the Smart-Tip™ probe across the suspect powder or surface.</td> <td>Place the absorbent paper of Smart-Tip™ probe into liquid. Make sure paper is wet.</td> </tr> </tbody> </table>	Powders & Traces	Liquids	Swipe the paper of the Smart-Tip™ probe across the suspect powder or surface.
Powders & Traces	Liquids						
Swipe the paper of the Smart-Tip™ probe across the suspect powder or surface.	Place the absorbent paper of Smart-Tip™ probe into liquid. Make sure paper is wet.						

Test Preparation	3	Lock Smart-Tip™ probe into test unit. Press firmly.	STOP Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit.	4	With thumb and forefinger , squeeze chamber 1 until capsule breaks.	5	Gently shake test unit for 2-3 seconds.
				Identification			

Identification	6	With thumb and forefinger , squeeze chamber 2 until capsule breaks.	7	Gently shake test unit for 2-3 seconds.

Results		The immediate appearance of a purple-red color on the paper or in the liquid, as viewed in either the front or back window, indicates the presence of one of these 50 suspected drugs: Heroin, Amphetamine, Methamphetamine, Ecstasy/MDMA, Methadone, Ketamine, PCP, PMA, DMT, MDPV, Mephedrone, PMMA, mCPP, MPA, 2-aminoindane (2-AI), MDMAI, Buphedrone, MDPBP, Cathinone, Methcathinone, Methylone, Pentylone, 3-Methylbutyrfentanyl, 3-Methylfentanyl, 4-Fluorobutyrfentanyl, 4-Fluoroisobutyrfentanyl, 4-Methoxybutyrfentanyl, 4-Fluorofentanyl, Acetylfentanyl, Acrylfentanyl, α-Methylfentanyl, Butyrfentanyl, Cyclopropylfentanyl, 2-FMA, EAPB, 3,4-DMMC, Benzedrone, Mexedrone, Pentedrone, Diphenylprolinol, Naphyrone, Indapryphenidone, Thiothinone, Diphenidine, Ephendine, Fluorolintane, or Benzylpiperazine.
		The immediate appearance of a green or blue-green color on the paper or in the liquid, as viewed in either the front or back window, indicates the presence of Cocaine/Crack .
		If none of the above colors develop immediately, the above listed drugs are not present. Note: A change of color on the sampler itself is a normal part of the process and does not indicate a positive result.

Disposal	The test kit is safe to dispose of in the trash.
-----------------	--